



Aquamart is able to test for physical parameters of water such as: Hardness, pH, Total Dissolved Solids (TDS), as well as Iron & Tannin content in water.

If you have your own well & require bacteriological testing, please contact:

Simcoe Muskoka District Health Unit (705) 721-7520

****Specific sample bottles are required for bacteriological testing****

Taking Home Water Samples

1. Use a clean, empty vessel (at least 250mL)
2. Open tap & run water for at least 60 seconds prior to taking samples
3. Collect the following samples:

For Water Softeners:

Collect samples from both **HOT & COLD** taps in a bathroom

- a. Temperature of samples does not need to be maintained
- b. Bring into store for testing within 24hrs

For Drinking Water Systems:

Collect one sample from the **Kitchen COLD** tap and one from the **Drinking Water** tap

Aquamart – 110 Anne Street S. – Barrie, ON – (705) 721-4060